

# No More Air Loss or Water Leaks Around Your Windows and Doors



+



=



S  
A  
V  
I  
N  
G  
S

## Log Gap Cap

Pre-cut foam inserts

## Energy Seal

Log home sealant



## How to Seal Step-by-Step:

1. Use masking tape around the window or door seam.

2. Insert Log Gap Cap into the crevice using trowel. Log Gap Cap provides an even surface for sealant application and makes it easier to apply a uniform thickness across the gap.

3. Apply Energy Seal™ and tool smooth.

4. Remove masking tape as soon as tooling is complete.



For more information call us

**PERMA-CHINK**  
SYSTEMS, INC.

1-800-548-3554  
or visit [www.permachink.com](http://www.permachink.com)